

Quick User Guide

ONE.618 omnee.m MK2
Active Full-range Hi-Fi Speaker
(Speaker + Amplifier + Streamer)

August, 2025



Welcome to the **ONE.618 omnee.m MK2** Active Full-range Hi-Fi Speaker Quick User Guide. This concise guide offers clear instructions to swiftly set up and enjoy your speaker. While we recommend reviewing the full User Guide for a complete understanding, if you're eager to use your speaker promptly, let's dive in!

Speaker Overview

The **ONE.618 omnee.m MK2** is an advanced all-in-one wireless concrete speaker. Features built-in amplification and versatile streaming capabilities.

Getting Started

- Carefully unpack the speaker from the transport case, preserving the case for future transportation.
- Assemble the optional speaker stand following provided instructions.
- Place the speaker on the stand, aligning stand with speaker feet.

Speaker Placement

- Choose a central location for balanced sound distribution.
- Maintain around 2 meters of distance from walls to minimize sound reflections.
- Position the speaker at or slightly above ear level when seated.

Charging the Battery

- Fully charge the speaker's battery before initial use.
- Use the provided USB-C PD/QC adapter (45W) and USB-C cable with magnetic connector.
- Connect the USB-C cable to the adapter, then connect the magnetic end to the charging port on the base bottom at the back.
- You can use your speaker while charging it.

Initial Setup

- Switch on the speaker using the Main Power Switch and wait for startup sequence (about 10-15 seconds).
- Ensure your controlling device and speaker are connected to the same wireless network, supporting both 2.4GHz and 5GHz bands.

iOS Setup Method:

- On your iPhone or iPad, go to Settings → Wi-Fi.
- Look for "Set up new AirPlay Speaker" section and select your omnee.m speaker from the list.
- Choose your wireless network and enter WiFi password if required.
- Your speaker will connect automatically and appear in the 4Stream app without additional setup.

4Stream App Method (All Devices):

- Download the "4STREAM" app from your device's app store, or scan QR codes for quick access.

Apple App Store



Google Play Store



- Launch the 4Stream app and follow the on-screen instructions to connect the speaker to your Wi-Fi network.
- Make sure your controlling device is connected to the same Wi-Fi network as the speaker during setup.
- Add the speaker to your app and select the appropriate network.
- Do not interrupt or turn off the speaker during a firmware update (updates can begin automatically once an internet connection is established).

Controls and Functions

- Use the Base Touch Interface to control music sources, volume, playback, and check the battery level.
- For your convenience, utilize the included IR Remote Control or the Speaker App.
- Adjust the enclosure illumination using the Illumination Touch Button on the base.
- Use the touch control disable switch on the base bottom for public installations.

Connections & Inputs

- Use a Bluetooth connection to pair with your devices.
- Use AirPlay for wireless streaming from your Apple devices.
- Standard version includes wireless connectivity only. Additional wired input options available in upgraded versions.

Maintenance and Safety

- Wipe the speaker's exterior gently with a damp, soft cloth to keep it clean.
- Avoid exposure to liquids or extreme temperatures.
- Keep the USB-C charging port clean and dry.

Additional Tips

- Find an extensive guide at one618.eu for more insights.
- Experiment with speaker placement for an optimal audio experience.
- Use 5GHz WiFi network for best streaming quality when available.
- The transport case includes shoulder straps and rolling wheels for easy mobility.

Important Notes

- Pay attention to the relatively heavy weight of the speaker (25kg), and be sure to place it on a stable surface.
- When positioning the speaker on the stand, aligning stand with speaker feet.

Troubleshooting

- Explore the full User Guide for more insights.
- Should any issues arise, consult the Troubleshooting section in the online guide.
- For iOS setup issues, ensure iOS 11.4 or later and check that "Set up new AirPlay Speaker" appears in WiFi settings.
- For charging issues, verify the 45W USB-C PD/QC adapter is being used and magnetic connector is properly attached.
- Reach out to our customer support for further assistance.

By following these steps, you'll be all set to start using your omnee.m MK2 speaker. Take time to explore its features, fine-tune your settings, and elevate your music experience. For more detailed information, refer to the comprehensive full version of User Guide..

Pictorial Diagrams

